
BMP: Spill Clean-Up



DESCRIPTION:

Practices to clean-up leakage/spillage of on-site materials that may be harmful to receiving waters.

APPLICATION:

All sites

GENERAL:

- Store controlled materials within a storage area.
- Educate personnel on prevention and clean-up techniques.
- Designate an Emergency Coordinator responsible for employing preventative practices and for providing spill response.
- Maintain a supply of clean-up equipment on-site and post a list of local response agencies with phone numbers.

METHODS:

- Clean-up spills/leaks immediately and remediate cause.
- Use as little water as possible. NEVER HOSE DOWN OR BURY SPILL CONTAMINATED MATERIAL.
- Use rags or absorbent material for clean-up. Excavate contaminated soils.
 Dispose of clean-up material and soil as hazardous waste.
- Document all spills with date, location, substance, volume, actions taken and other pertinent data.
- Contact local Fire Department and State Division of Environmental Response and Remediation (Phone #536-4100) for any spill of reportable quantity.

OBJECTIVES

Housekeeping Practices
 Contain Waste
 Minimize Disturbed Areas
 Stabilize Disturbed Areas
 Protect Slopes/Channels
 Control Site Perimeter
 Control Internal Erosion



PIONEERING UTAH'S FUTURE Adapted from Salt lake county BMP fact sheet

TARGETED POLLUTANTS

□ Sediment

□ Nutrients

Toxic Materials

🗵 Oil & Grease

Floatable Materials
 Other Waste

- High Impact
- Medium Impact

□ Low or Unknown Impact

IMPLEMENTATION REQUIREMENTS

Capital Costs
O&M Costs
Maintenance
Training

■ High 🗵 Medium 🗆 Low

SCU